

Portable Water Softener

SOFTENER EXCHANGE RESIN REFILL & REPLACEMENT INSTRUCTIONS

1. Shut off the water supply and unthread the gray head from the blue tank.
2. Empty remaining resin into a waste container and rinse out tank.
 - Resin is environmentally safe and can be disposed through routine waste disposal process.
 - Distributor tube basket assembly will be removed during this procedure.
3. **Return distributor tube** into the tank, **slip/place rubber cap** over top of tube and then **place funnel** into top of the tank.
 - Ready to recharge unit with softener resin
4. **Slowly pour or scoop** resin into the tank. **Shake or tap** tank to get all of the resin bedded.
 - Standard Softener refill kit comes with one 10lb bag.
 - Double Standard Softener refill kits comes with one 20lb.
5. Remove funnel and rubber cap.
6. **Make sure all o-rings** are properly seated.

Insure seating areas are free from foreign material, apply silicone lubricant to both the distribution tube O-ring and the head O-ring.

7. You are now ready to replace the gray head.
8. Turn on water supply.
9. Flush system for 2-3 minutes for the Standard Softener and 4-6 minutes for the Double Standard Softener.

Tool kit included: Funnel, Rubber cap, Silicone lubricant, Resin

Refill Kit Video

https://www.youtube.com/watch?v=usg9Rmt9_60